

SNMP Settings

For SNMP V3 use:

```
snmp-server user prtg v3ReadOnlyG v3 auth sha priv aes128
```

Set Password

```
copy run start
```

From:

<https://wiki.buergi.org/> - **Reto's WIKI**

Permanent link:

<https://wiki.buergi.org/doku.php?id=avaya:mgw:snmp>

Last update: **2026/01/20 22:45**

